

Assembly Instructions

Ultra Single-Side Bike Rack, 7-Bike Capacity- BRP300


Ultra Single-Side Custom Logo Bike Rack, 7-Bike Capacity - BRP300-CUST

Tools Needed


9/16" Wrench
9/16" Socket with Ratchet



Component Parts



End Sections (Qty 2)




Center Section (Qty 1)



Support (Qty 1)

Hardware Included



3/8" x 1.5" Hex Head Bolt
(Qty 12)



3/8" Flanged Nut
(Qty 12)



3/8" Flat Washer
(Qty 24)




Assembly Instructions

This assembly is a two-person operation.

1. Inspect the shipping container contents for damaged or missing components.
2. Lay all parts on a soft work surface or one the shipping packaging to prevent damage to finish.


NOTE: Before Assembly, it is recommended that a light oil or petroleum jelly be applied to any threads.

3. One at a time, align Center Section holes above End Section holes as shown.
4. Using 4 bolts, 4 nuts, and 8 washers, secure the Center Section to the End Section as shown.
5. Repeat to secure the other side of the Center Section to the other End Section. Tighten all hardware finger tight so adjustments can be made during assembly.
6. Align both Supports' holes above End Section holes as shown.
7. Using 2 bolts, 2 nuts, and 4 washers, secure the Support to the End Section as shown.
8. Repeat to secure the other side of the Support to the other End Section. Tighten all hardware finger tight so adjustments can be made during assembly.
9. After everything is in place, tighten all hardware with the ratchet and 9/16" wrench. Re-tighten all hardware after two weeks.



Replacement Parts

Contact us at **1-866-797-1761** to order replacement parts.



WARNING

- Furniture must not be used other than for its intended purpose and should be inspected regularly for loose, missing, or broken hardware, and general instability.
- Furniture that is damaged or appears to be unstable must be removed from service and repaired or replaced.
- Repairs must be made using only factory authorized parts and methods.

CARE AND MAINTENANCE

- Do not drag the assembled unit across any surface.
- This product requires only periodic cleaning with a sponge and a solution of mild detergent and water to remove surface dirt.
- Do not clean with a solvent or petroleum based products.

Manufactured in the U.S.