

**ASSEMBLY INSTRUCTIONS
 PCS30HT & E30AGHT**

PCS30HT



- TOOLS NEEDED:**
- Phillips Screwdriver


E30AGHT



- TOOLS NEEDED:**
- None


The 30-gallon receptacle arrives fully assembled and ready to use. This instruction describes how to attach the Lid Security Straps to the receptacle.

1. Attach the snap hook on one of the straps to one of the clip rings attached to the inside of the lid.
2. Insert one of the provided screws through the hole at the other end of the strap and into the threaded insert embedded in the wall of the receptacle.



The 30-gallon receptacle arrives fully assembled and ready to use. This instruction describes how to attach the Lid Security Straps to the receptacle.

1. Insert the provided quick-connect through the hole in the end of the strap and through the clip ring inside the lid and close the quick-connect.
2. Connect the snap hook on the other end of the strap to the D-ring attached inside the frame of the receptacle.



CARE AND MAINTENANCE

- Do not drag the assembled unit across any surface.
- This product requires only periodic cleaning with a sponge and a solution of mild detergent and water to remove surface dirt. Do not clean with a solvent or petroleum based products.



WARNING

- Furniture must not be used other than for its intended purpose and should be inspected regularly for loose, missing, or broken hardware, and general instability.
- Furniture that is damaged or appears to be unstable must be removed from service and be repaired or replaced.
- Repairs must be made using only factory authorized parts and methods.